1. コインを投入して下さい。
2. 今日の日付(年月日)を入れて下さい。
   操作ボタンの説明

← LEFT	→ RIGHT	○ PRESS	× PRESS
青	黄	白	赤
左に動く	右に動く	正しい	まちがい

   1～9の数字の前には0(ゼロ)を押して下さい
   (例 昭和57年07月06日)
3. インプットが終ったら　最後に白のPRESSボタンを押して下さい。
4. 名前を入れて下さい。インプットが終りましたら最後にZの右側にある (エンド　マーク)の位置で白のPRESSボタンを押して下さい。
5. 性別を入れて下さい。次に白のPRESSボタンを押して下さい。
6. 誕生日を入れて下さい。(日付のインプットの方法は2の説明と同様)
   明治、大正、昭和(上段)で合せた後、もう一度白のPRESSボタンを押すと、日付(下段)に移ります
7. 1～6までインプットした内容が出ます。正しかったら白のPRESSボタンを、まちがっていたら赤のPRESSボタンを押してインプットしなおして下さい。
8. プリンターが占いを打ち出します。多少時間がかかりますので、しばらくお待ち下さい。
   (アウトプットするまでの時間約5分)

HOW TO PLAY

1. Put a coin into the slot
2. Input today's date
   Control Buttons

← Left	→ Right	○ Press	× Press
Blue	Yellow	White	Red
move left	move right	correct	incorrect

   Push the 0 (zero) button before you push a one-digit number
   (Ex. SHOWA 57 year, 07 month, 06 day)
3. Push the white PRESS button.
4. Input your name And then, push the white PRESS button at the position of end mark to the right of Z
5. Input your sex And then push the white PRESS button
6. Input your birth date as in 2. Choose MEIJI, TAISHO or SHOWA in the upper column And then push the white PRESS button again. You will move to the date section in the lower column
7. You can see what you have inputted. If the inputted data is correct, push the white PRESS button. If it is incorrect, push the red PRESS button and input the correct data.
8. Please wait for about 5 minutes until the PRINTER types out your fortune.

株式会社 ショウエイ

〒183 東京都府中市天神町4－3－9
TEL 0423-66-2664(代)　TELEX 2832548

4-3-9 Tenjincho Fuchu Shi, Tokyo JAPAN
TELEPHONE 0423-66-2664　TELEX 2832548 SHOEI J